



PVC Pipe T-Stand

(When assembling stand and base, do not cement together until you are very sure that you have double checked for accuracy)

Shoulder Measurements for Stand Cuts

Shoulder Widths	2 pieces of PVC of this measurement
12"	5"
12 1/2"	5 1/4"
13	5 1/2"
13 1/2"	5 3/4"
14"	6"
14 1/2"	6 1/4"
15"	6 1/2"
15 1/2"	7 3/4"
16"	7"
16 1/2"	7 1/4"
17"	7 1/2"
17 1/2"	7 3/4"

Please go to <http://dressformdesigning.com/measurements/> to see the illustration on how to measure from FRONT armpit to FRONT armpit---NOT Back armpits!